




CABINET PARTS

For Models: ET1PHKXPQ02, ET1PHKXPT02
(White) (Biscuit)

REFRIGERATOR



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: ET1PHKXPQ02, ET1PHKXPT02
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	2314273	Service & Wiring Sheet
	2302183	Energy Label
	2302037	Use & Care Guide
	2225413	Customer Instructions

Following May Be Purchased


DO-IT-YOURSELF REPAIR MANUALS

	677969	Do-It-Yourself Manual, Ref./Fzr.
2	2189410	Hinge (Top)
3	2166108	Roller, Front (2)
4	489427	Screw
5	489385	Clamp, Tube (Water Supply Line)
9	489341	Washer
10	2179826	Rivet
11	3400504	Screw
12	549193	Clamp, Cord
15	489497	Screw
16	2183972	Hinge, Center
17	2183854	Shim, Hinge Center
18	8281265	Screw
20	2254473	Hinge Butt
24		Fitting, Water Tube (Not Serviced)
27		Hole Plug (6)
	2201012	White
	2200924	Biscuit
28		Seal, Front (Not Serviced)
30		Seal, Rear (Not Serviced)
35		Corner Filler (2)
	2201014	White
	2200926	Biscuit
36		Grille (Includes Illus. 37)
	2254313	White
	2254316	Biscuit
37	2189356	Clip, Grille (2)
38	487576	Washer
40		Cover, Hinge
	2213360	White
	2213364	Biscuit
41		Rail, Center (Not Serviced)
44	2202884	Cover, Unit
45		Cabinet (Not a Serviceable Part)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: ET1PHKXPQ02, ET1PHKXPT02
(White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: ET1PHKXPQ02, ET1PHKXPT02
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes Illus. 2,3,9 & 22)
	2183920	White
	2205284	Biscuit
2	939101	Screw Anchor
3	2183198	Tap Plate
5		Handle, Refrigerator
	2202807W	White
	2202807T	Biscuit
6	489357	Screw
8	8281146	Screw
9	2202875	Door Gasket, Magnetic
12		Cover, Screw
	2202819W	White
	2202819T	Biscuit
13	2262218	Nameplate
16	2195378	Trim, Door Shelf
17	8281206	Screw
19		Freezer Door (Includes Illus. 3,22 & 23)
	2182489	White
	2204686	Biscuit
20		Hole Plug, Handle
	2189000	White
	2200936	Biscuit
21	2188236	Shelf, Flip-Up
22	2183003	Thimble
23	2214967	Door Gasket, Magnetic
25	2204812	Bin, Door Shelf
26	2189202	Bracket, Door Stop (2)
27	488921	Screw
28		Hole Plug
	2212648	White
	2212649	Biscuit
29	2156007	Plug, Trim
30	2156006	Plug, Trim
31	2218118	Compartment Door
33		Handle, Freezer
	2202806W	White
	2202806T	Biscuit
37	2195947	Trim, Door (2)
41	2195916	Endcap, Trim (4)
42	2195948	Trim, Door

For Models: ET1PHKXPQ02, ET1PHKXPT02
(White) (Biscuit)

(White) (Biscuit)

33

34

1

18

15

2

10

2

29

6

32

14

3

3

14

27

23

16

11

26

31

24

21

28

19

4

9

5

17

8

13

7

12

35

22

14

8199389

LINER PARTS


For Models: ET1PHKXPQ02, ET1PHKXPT02
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not a Serviceable Part)
2	2197380	Grommet (2)
3	2254360	Gasket, Evaporator Cover (2)
4	2314156	Defrost Timer
5	2204640	Thermostat, Tube Barrier
6	941839	Hole Plug
7	2187885	Wire Assembly Control Box
8	2162085	Socket, Light
9	98129	Screw (2)
10	2214986	Fan Motor
11	2163777	Fan Blade
12	2218381	Control Box
13	2225460	Thermostat
14	489478	Screw
15	488208	Screw
16	2254263	Cover, Evaporator
17	2160708	Light Bulb
18	2254454	Bracket
19	1118894	Evap. Fan, Rear Switch, Rocker Arm
21	2176281	Cover, Air Diffuser
22	2202885	Knob, Thermostat
23	2254354	Air Tower
24	2189452	Air Diffuser, Bottom
26	2212439	Air Separator Assembly
27	2205003	Cover, Hole
28	2171931	Valve-Tube, Body
29	2254453	Bracket, Fan Motor
31	2204639	Shield, Heat
32	487996	Cap
33	2310043	Wire Assembly Freezer Compartment (Includes Item 34)
34	2314158	Defrost, BI-Metal
35	940014	Hole Plug, Control Box

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: ET1PHKXPQ02, ET1PHKXPT02
(White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: ET1PHKXPQ02, ET1PHKXPT02
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	2225596	Plate, Unit Mounting
2	2183454	Relay (Service Only)
3	2214960	Condenser
4	2314157	Heater, Defrost
5	2221761	Evaporator Assy.
6	8533859	Screw
7	2254295	Drain Pan
8	2169104	Insulation, Sound Dampening
9	2176301	Bracket, Heater
10	2300638	Extension, Air Baffle
11	2255113	Strap
12	4387731	Cover (Service Only)
13	4390624	Overload (Service Only)
14		Grommet (4)
	1100826	Production
	4387558	Service
15	2225785	Start-Device Combination (Start Relay and Overload for Production Compressor Only)

Illus. No.	Part No.	DESCRIPTION
17	2150304	Roller (2)
18	2221797	Rivet
19	2182338	Clip, Heater
20	489373	Screw
22	4387765	Wire Assembly (Service Only)
23	2201185	Support Block
24	3400518	Screw
28	2225833	Compressor (Includes Items 2, 12, 13, 14, 22, 29 & 32)
29		Drier
	2199167	Production
	4387019	Service
30	2155774	Clamp
32		Capacitor
	2169373	Production
	1118576	Service
39	2302249	Air Baffle
40	2188874	Motor, Condenser
42	2187382	Wire Assy, Unit
43	2225834	Fan Blade
46	2225564	Tube, Discharge
47	2225565	Tube, Suction
48	2154109	Tube, Process
56	488500	Screw
58	2300635	Tray, Evaporator

Illus. No.	Part No.	DESCRIPTION
Following Parts Not Illustrated and Optional Parts Not Included		
	978025	Valve, Access (1/4")
	978026	Valve, Access (5/16")
	978027	Valve, Access (3/8")
	978028	Valve, Access (1/2")
	978029	Valve, Access (5/8")
	978030	Valve, Access (3/4")
	876764	Valve, Access (3/16")

REFRIGERANT CHARGE


4.00 Ozs.
(R134A)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

SHELF PARTS

For Models: ET1PHKXPQ02, ET1PHKXPT02
(White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	2210522	Shelf, Ladder (2)
2	2300520	Shelf, Ladder Center
4	2163762	Cup, Shelf Mtg.
5	489478	Screw
6	2188687	Trim Shelf, Rear
7	2201102E	Shelf, Cantilever
8	2188685	Trim, Shelf Front
9	2210526	Crisper Cover
11	2210573	Insert, Crisper Cover
12	2201106	Pan Shelf, Cantilever
14	2200987	Glass, Shelf
15	2163832	Crisper Support
17	2189454	Shelf, Freezer
19	2188711	Trim Shelf, Side
20	2218132K	Pan, Meat
24	2218141	Crisper Pan (Includes 25 & 26)
25	2212446	Body, Humidity Control
26	2176222	Slide, Humidity Control

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: ET1PHKXPQ02, ET1PHKXPT02
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
Parts Not Illustrated and Optional Parts (Not Included)		
	978941	Insulation, Fiberglass (63-1/2" x 35-1/2" x 2-5/8")
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4" x 108")
	876305	Kit, Insulation (14 Pcs. 3" x 24" x 48")
	876370	Kit, Insulation (2 Pcs. 3" x 24" x 48")
	876029	Kit, Foam Slab (30" x 32-1/2" x 1-1/2")
	505587	Sealer, Mastic (1 Qt.)
	511873	Touch-Up, White Porcelain (2 Oz.)
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1-1/4 Oz.)
	606755	Bag, Insulation (36-5/8" x 46")
	799833	Kit, Evaporator Repair (Aluminum Epoxy)
	799832	Kit, Porcelain Repair (White)
	503695	Cork Sealer (1/4 Pound)

Illus. No.	Part No.	DESCRIPTION
Customer Touch-Up Material		
	*350942	Primer, White (12 Oz. Spray Can)
	*350939	Enamel, Black (12 Oz. Spray Can)
	*350930	Enamel, White (12 Oz. Spray Can)
	*4392901	Enamel, Biscuit (12 Oz. Spray Can)
	72017	Brush Touch-Up Kit (White)
	72032	Brush Touch-Up Kit (Black)
	4392899	Brush Touch-Up Kit (Biscuit)
Refinishing Material		
	799340	Enamel, Black (1 Qt. Uncut)
	799344	Enamel, White (1 Qt. Uncut)
	4392900	Enamel, Biscuit (1 Qt. Uncut)
	833938	Kit, Terminal Connector
<p>*Important: The spray paint is not to be used where the paint may make contact with the door gaskets.</p>		

Illus. No.	Part No.	DESCRIPTION
ICE MAKER FIELD INSTALLABLE		
	2155469	ECKMF94
TORX SCREW WRENCH		
	1117510	Torx Key